



# Test kit for performing titrimetric tests on sulfite ions in surface water and sewage

### Method:

# Iodometric titration

#### Contents of test kit:

sufficient for 60 tests at an average sulfite content of 10 mg/L  $\mathrm{SO_3^{2-}}$ 

- 20 mL SO<sub>3</sub>-1
- 20 mL SO<sub>3</sub>-2
- 30 mL SO<sub>3</sub>-3
  - 1 specimen jar with ringed markings
  - 1 plastic syringe 5 mL
- 1 instructions for use

# Hazard warning:

Information regarding safety can be found on the box' label and in the safety data sheet. You can download the SDS from www.mn-net.com/SDS.

#### Instructions for use:

- Pour a 5 mL water sample into the specimen jar using the plastic syringe.
- 2. Add 5 drops SO<sub>3</sub>-1.
- 3. Add 5 drops of SO<sub>3</sub>-2 and shake the jar to mix the contents.
- Hold the dropping bottle SO<sub>3</sub>-3 absolutely vertical and add the reagent drop by drop while smootly shaking the specimen jar until the colour turns from colourless to blue. Count the number of drops. 1 drop corresponds to 1 mg/L SO<sub>3</sub><sup>2-</sup>.
- 5. After use, rinse out the specimen jar thoroughly with distilled water.
- Seal the dropping bottles immediately after use. Do not touch the dropping pipettes.

The method can be applied also for the analysis of sea water.

# Disposing of the samples:

Information regarding disposal can be found in the safety data sheet. You can download the SDS from *www.mn-net.com/SDS*.

# Interferences:

Oxidizing and reducing substances interfere with the determination.

1 mg/L ascorbic acid  $\triangleq$  0.5 mg/L SO<sub>3</sub><sup>2-</sup>.

# Note:

For the determination of dithionite contact MACHEREY-NAGEL for special working instructions.

#### **Conversion table:**

drops	mg/L SO <sub>3</sub> <sup>2-</sup>	mg/L Na <sub>2</sub> SO <sub>3</sub>
1	1	2
2	2	3
3	3	5
4	4	6
5	5	8
6	6	9
7	7	11
8	8	13
9	9	14
10	10	16

Storage:

Store the test kit in a cool (< 25 °C) and dry place.